



Customer Name:	U.S. Micro Solutions, Inc.	Sample Date:	May 9, 2017
Customer Address:	1075 South Main Street, Suite 104 Greensburg, PA 15601	Date Received:	May 11, 2017
		Date of Report:	May 16, 2017
Customer Phone:	(724) 853-4047	Fax:	(724) 853-4049
PO Number:		Attention:	
Project Name/Number:	Sample Bioaerosol Report		

Customer sample numbers below are uniquely identified by prefixing Laboratory # 12345-17

Culturable Bioaerosol Sample(s) (Sets) - Analytical Method USMS-M002 & USMS-B002

Sample Number	Media	Sample Description	Results of Microbial Analysis	%	Raw CTs		
1	TSA	Room 1	Total Bacterial Count	< 18	CFU/m ³ of air		
			<i>No growth</i>				
Total Raw Count: <1 Total Volume: 56.6 liters of air Analytical Sensitivity: 18 CFU/m ³ of air							
1	IMA	Room 1	Total Fungal Count	14	CFU/m ³ of air		
					<i>Non-sporulating hyaline fungus</i>	75%	3
					<i>Penicillium spp.</i>	25%	1
Total Raw Count: 4 Total Volume: 283.0 liters of air Analytical Sensitivity: 4 CFU/m ³ of air							
2	TSA	Room 2	Total Bacterial Count	35	CFU/m ³ of air		
					<i>Micrococcus/Kocuria spp.</i>	50%	1
				<i>Coagulase-negative Staphylococcus spp.</i>	50%	1	
Total Raw Count: 2 Total Volume: 56.6 liters of air Analytical Sensitivity: 18 CFU/m ³ of air							
2	IMA	Room 2	Total Fungal Count	< 4	CFU/m ³ of air		
			<i>No growth</i>				
Total Raw Count: <1 Total Volume: 283.0 liters of air Analytical Sensitivity: 4 CFU/m ³ of air							

Results relate only to the samples tested. Results are reported as calculated. For biological data, the first and/or second digit should be considered significant. Total percentages may not equal 100% due to rounding.

When providing duplicates of this report, the document should be provided in total and not in section in accordance with AIHA-LAP, LLC. Any unauthorized or improper disclosure, copying, distribution, use, or falsification of these results is prohibited. USMS shall have no liability to the Customer or the Customer's customer for opinions stated, recommendations made, actions taken, or conduct implemented based on the test results reported.

Technical Manager:

Herbert Layman

End of Report